



Installation Instructions  
for  
NightCrawler™ *Modular* Front Bumper  
for '87-'95 Jeep® YJ Wrangler

Thank you for purchasing your new Skid Row Offroad NightCrawler™ *Modular* front bumper. It is designed to give you peace of mind while traversing even the toughest trails.

Your bumper package should come complete with the following parts:

- |                                   |                                 |
|-----------------------------------|---------------------------------|
| 1. (1) Bumper                     | 4. (6) ½” Flat Washer           |
| 2. (6) ½-13 x 1.25” Hex Head Bolt | 5. (2) 3/16” thick spacers      |
| 3. (6) ½” Lock Washer             | 6. (4) 2” Round Spotter’s Lamps |

If ordered with a skid plate it will also have the following parts:

- |                                |                        |
|--------------------------------|------------------------|
| 1. (1) ¼” Thick Skid Plate     | 4. (4) 3/8 Lock Washer |
| 2. (4) 3/8-16x1” Carriage Bolt | 5. (4) 3/8-16 Hex Nut  |
| 3. (4) 3/8 Flat Washer         |                        |

If ordered with a 2” Receiver it will also have the following parts:

- |                                |                                |
|--------------------------------|--------------------------------|
| 1. (1) Bolt-in 2” Receiver     | 6. (1) 3/8-16x1” Carriage Bolt |
| 2. (1) 5/8-18x4” Hex Head Bolt | 7. (1) 3/8-16 Hex Nut          |
| 3. (1) 5/8-18 Hex Nut          | 8. (1) 3/8 Flat Washer         |
| 4. (1) 5/8 Lock Washer         | 9. (1) 3/8 Lock Washer         |
| 5. (2) 5/8 Flat Washer         |                                |

**Installation Notes:**

1. Installing a winch should be done before installing the bumper.
2. It is easier to install the screw clevis plates and bumper extensions with the bumper off the vehicle.
3. If you are not using the screw clevis plates or bumper extensions, tow hooks can be installed on each side of the bumper using the holes closest to the winch mounting plate.
4. We do not have a wiring kit for the Spotter’s Lamps™ that are included with the bumper.
5. Always use a fused circuit to wire the Spotter’s Lamps.
6. The Spotter’s Lamps™ should not be wired to your headlight circuit as they are for offroad use only.

**Step 1:** Remove the current front bumper.

**Step 2:** If using the skid plate, bolt it to the bumper using the hardware provided.

**Step 3:** If using the Bolt-in 2" Receiver slide it into place with the small hole at the rear to the bottom. Install the 5/8-18x4" hex head bolt using a flat washer under the head of the bolt. Then place a flat washer, lock washer, and nut onto the bolt. Install the 3/8-16x1" carriage bolt through the bottom of the bumper and install the flat washer, lock washer, and nut. Tighten the 3/8-16 nut. Then torque the 5/8-18x4" bolt to 100-110 ft-lbs.

**Step 4:** Place the bumper on the chassis and slide the two spacers between the bumper and the chassis. One per side.

**Step 5:** Install the six 1/2-13x1.25 hex head bolts or your original Torx bolts.

**Step 6:** Torque the mounting bolts to 80 ft-lbs (108 N-m) once everything is fit together and you're done.

We hope you enjoy your new Skid Row Offroad NightCrawler™ *Modular* front bumper!  
Sincerely,

**The Staff at SFK Manufacturing, LLC**



*You could win a cool Skid Row Offroad  
jacket customized just for you  
by registering your new purchase at  
[www.SkidRowOffroad.com/registration/](http://www.SkidRowOffroad.com/registration/)*

Annual Drawing to be held January 1<sup>st</sup>. Winner to be selected from all entries from prior year.  
All entries must be received by December 31<sup>st</sup> to be included in drawing.  
One entry per person per Skid Row Offroad product purchased.

**SFK Manufacturing, LLC**  
PO Box 306, Shermans Dale, PA 17090  
Phone 717-582-3640  
Fax 717-582-2640

[www.SkidRowOffroad.com](http://www.SkidRowOffroad.com)