



Installation Instructions
for
Mirror Relocation Brackets for
1987-1995 Jeep® YJ Wrangler

Thank you for purchasing your new Skid Row Offroad Mirror Relocation Brackets. They are designed for your convenience both on and off the trail.

Your package should come complete with the following parts:

LEFT

- (1) Left Side Mirror Relocation Bracket
- (2) 5/16" Stainless Steel Flat Washers
- (2) 5/16-18 x .75" Button Head Cap Screws

RIGHT

- (1) Right Side Mirror Relocation Bracket
- (2) 5/16" Stainless Steel Flat Washers
- (2) 5/16-18 x .75" Button Head Cap Screws



If only one side was ordered, then only the parts for that side are included.



- Step 1:** Remove the original Torx head bolts from the sides of the upper part of the windshield hinge.
Step 2: Place one of the stainless steel 5/16" flat washers on each of the 5/16-18 Stainless Button Head Cap Screws and bolt the mirror bracket to the hinge as shown.
Step 3: Disassemble the mirror from the original mirror mounting bracket saving the nut and flat washer to be re-used.
Step 4: Remove the original mirror mounting bracket from the door.
Step 5: Mount the mirror into the new mirror relocation bracket using the flat washer and nut. Position the mirror and tighten the nut.

We hope you enjoy your new Skid Row Offroad mirror relocation brackets!

Sincerely,

The Staff at SFK Manufacturing, LLC

SFK Manufacturing, LLC
Box 306, Shermans Dale, PA 17
Phone 717-582-3640
Fax 717-582-2640

www.SkidRowOffroad.com



*You could win a cool Skid Row Offroad
jacket customized just for you
by registering your new purchase at
www.SkidRowOffroad.com/registration/*

Annual Drawing to be held January 1st. Winner to be selected from all entries from prior year.
All entries must be received by December 31st to be included in drawing.
One entry per person per Skid Row Offroad product purchased.