



Installation Instructions
for
Screw Clevis Plates
for use with
NightCrawler™ Modular Bumpers

Thank you for purchasing your new Skid Row Offroad Screw Clevis Plates for your NightCrawler™ Modular bumper. They are designed to give you peace of mind while traversing even the toughest trails.

Your Screw Clevis Plate package should come complete with the following parts:

- | | |
|-----------------------------------|------------------------|
| 1. (2) Screw Clevis Plates | 3. (8) ½” Lock Washer |
| 2. (8) ½ -13 x 2.5” Hex Head Bolt | 4. (16) ½” Flat Washer |
| 5. (8) ½ -13 Hex Nut | |

Step 1: The bumper does not need to be removed to install the screw clevis plates, although in the front it may be easier if the bumper is removed.

Step 2: Install each screw clevis plate using four of the ½-13x2.5 hex head bolts provided. Place a flat washer under the head of each bolt and then install a flat washer, lock washer, and hex nut on each bolt.

Step 3: Torque the mounting bolts to 80 ft-lbs (108 N-m) once everything is fit together and you're done.

We hope you enjoy your new Skid Row Offroad NightCrawler™ Modular bumper screw clevis plates!

Sincerely,

The Staff at SFK Manufacturing, LLC

SFK Manufacturing, LLC
PO Box 306, Shermans Dale,
PA 17090
Phone 717-582-3640
Fax 717-582-2640

www.SkidRowOffroad.com



You could win a cool Skid Row Offroad jacket customized just for you by registering your new purchase at www.SkidRowOffroad.com/registration/

Annual Drawing to be held January 1st. Winner to be selected from all entries from prior year. All entries must be received by December 31st to be included in drawing. One entry per person per Skid Row Offroad product purchased.