



Installation Instructions for Gas Tank Skid Plate for 2000-2004 Nissan Xterra

Thank you for purchasing your new Skid Row Offroad gas tank skid plate. It is designed to give you peace of mind while traversing even the toughest trails.



Step 1: Remove the factory gas tank “skid plate”.

Step 2: Using a floor jack, raise the new gas tank skid plate into position and install the two M10x1.25 bolts through the rear flange of the skid plate. **NOTE: It is easy to cross-thread these bolts! Be careful.**

Also, note that there is limited clearance around one of the bolts for a socket. A 3/8”-drive socket may be needed due to its smaller outside diameter.

Step 3: Once the holes at the front of the skid plate are aligned with the threaded holes in the chassis, install the two remaining M10x1.25 bolts, again being careful not to cross-thread them.

Step 4: Tighten all bolts and the installation is complete.



We hope you enjoy your new Skid Row Offroad gas tank skid plate!
Sincerely,

The Staff at SFK Manufacturing, LLC

SFK Manufacturing, LLC
PO Box 306, Shermans Dale, PA 17090
717-701-8315
Fax 717-701-8316

www.SkidRowOffroad.com