



Installation Instructions  
for  
Front Skid Plate, TA-0002  
for  
1995-2004 Toyota Tacoma or  
1996-2002 Toyota 4Runner

Thank you for purchasing your new Skid Row Offroad front skid plate. It is designed to give you peace of mind while traversing even the toughest trails.

Your skid plate package should come complete with the following parts:

- 1. (1) Front Skid Plate
- 2. No additional hardware is provided. Re-use the original hardware from the factory skid plate.

**Step 1:** Remove the factory “skid plate” from the front of the vehicle. Retain the original hardware as it will be re-used. If you are missing the original bolts, they are M8-1.25x 20mm hex head bolts with flat washers.

**Step 2:** Lift the new front skid plate into place as shown to the right and bolt in place using the original hardware.

**Step 3:** Tighten all seven bolts and you’re ready to hit the trail!

We hope you enjoy your new Skid Row Offroad front skid plate!

Sincerely,

**The Staff at SFK Manufacturing, LLC**



**SFK Manufacturing, LLC**  
PO Box 306, Shermans Dale, PA 17090  
Phone 717-701-8315  
Fax 717-701-8316

[www.SkidRowOffroad.com](http://www.SkidRowOffroad.com)