



Installation Instructions
for
Front Skid Plate, TA-0002
for
1995-2004 Toyota Tacoma or
1996-2002 Toyota 4Runner

Thank you for purchasing your new Skid Row Offroad front skid plate. It is designed to give you peace of mind while traversing even the toughest trails.

Your skid plate package should come complete with the following parts:

1. (1) Front Skid Plate
2. No additional hardware is provided. Re-use the original hardware from the factory skid plate.

Step 1: Remove the factory “skid plate” from the front of the vehicle. Retain the original hardware as it will be re-used. If you are missing the original bolts, they are M8-1.25x 20mm hex head bolts with flat washers.

Step 2: Lift the new front skid plate into place as shown to the right and bolt in place using the original hardware.

Step 3: Tighten all seven bolts and you’re ready to hit the trail!

We hope you enjoy your new Skid Row Offroad front skid plate!

Sincerely,

The Staff at SFK Manufacturing, LLC



SFK Manufacturing, LLC
PO Box 306, Shermans Dale, PA 17090
Phone 717-582-3640
Fax 717-582-2640

www.SkidRowOffroad.com



You could win a cool Skid Row Offroad jacket customized just for you by registering your new purchase at www.SkidRowOffroad.com/registration/

Annual Drawing to be held January 1st. Winner to be selected from all entries from prior year. All entries must be received by December 31st to be included in drawing. One entry per person per Skid Row Offroad product purchased.